

Contents

	<i>Page</i>
Foreword	1
Resolution A.1048(27) Code of Safe Practice for Ships carrying Timber Deck Cargoes, 2011 (2011 TDC Code)	3
Preface	5
Chapter 1 – General	7
1.1 Purpose	7
1.2 Application	7
1.3 Definitions	8
Part A – Operational requirements	
Chapter 2 – General recommendations on stowage and securing of timber deck cargoes	11
2.1 Goals	11
2.2 Pre-loading operation	11
2.3 Permitted loading weights on decks and hatch covers	12
2.4 Stability	13
2.5 Load line	13
2.6 Timber freeboard	14
2.7 Visibility	14
2.8 Work safety and work environment aspects	14
2.9 Stowage	16
2.10 Securing	17
2.11 Post-loading operation	23

	<i>Page</i>
2.12 Voyage planning	24
2.13 Cargo securing manual	25
Chapter 3 – Visibility	27
Chapter 4 – Physical properties of timber cargoes	29
4.1 Stowage factors	29
4.2 Friction factors.....	30
4.3 Plastic covers.....	31
4.4 Package marking	32
4.6 Weight of ice.....	32
4.7 Rigidity of sawn wood packages	32
4.5 Water absorption.....	32
 Part B – Design of cargo securing arrangements	
Chapter 5 – Design principles	35
5.1 General.....	35
5.2 Uprights	37
5.3 Loose or packaged sawn wood	38
5.4 Logs, poles, cants or similar cargo	39
5.5 Testing, marking, examination and certification	39
5.6 Lashing plans.....	39
Chapter 6 – Alternative design principles	41
6.1 General requirements	41
6.2 Accelerations and forces acting on the cargo.....	42
6.3 Physical properties of timber deck cargoes	43
6.4 Safety factors.....	44
6.5 Design criteria for different securing arrangements.....	45
Chapter 7 – Uprights	53
Chapter 8 – Denotations used	55

	<i>Page</i>
Annex A – Guidance in developing procedures and checklists	57
A.1 Preparations before loading of timber deck cargoes	57
A.2 Safety during loading and securing of timber deck cargoes . . .	60
A.3 Securing of timber deck cargoes	62
A.4 Actions to be taken during the voyage	64
A.5 Safety during discharge of timber deck cargoes	67
Annex B – Samples of stowage and securing arrangements . . .	69
B.1 Example calculation: top-over lashings.	69
B.2 Example calculation: bottom blocking and top-over lashings . .	71
B.3 Example calculation: loop lashings.	74
B.4 Example calculation: uprights for packages of sawn wood	77
B.5 Example calculation: uprights for round wood	81
B.6 Example calculation: frictional securing of transversely stowed round wood.	90
B.7 Maximum bending resistance in common profiles for uprights	92
Annex C – Instruction to a master on calculation of mass change of a timber deck cargo due to water absorption	95
Annex D – References	97